

AL-RSV1000/1500-RK

1. 		Bearing	2. 		Bearing
		2 pcs			2 pcs
3. 		Seal	4. 		Sleeve
		4 pcs			4 pcs
5. 		O-ring Set			
		1 pc			