

Alcatel A100 Repair Kit

1. 		Bearing 2 pcs	2. 		Bearing 2 pcs
3. 		Bearing 1 pc	4. 		Seal 2 pcs
5. 		Adapter Bushing 2 pcs	6. 		Seal 2 pc
7. 		Washer 2 pcs	8. 		O-ring Set 1 pc