

Edwards ED80-IN Repair Kit

1. 	Bearings	2 PC
2. 	Coupling Insrt	1 PC
3. 	Bearings	2 PC
4. 	Sleeve	2 PC
5. 	Bearings	2 PC
6. 	Shaft Seal	2 PC
7. 	Sleeve	2 PC
8. 	Motor Sleeve	1 PC
9. 	Seal - Shaft	6 PC
10. 	Douty Seal	3 PC
11. 	O-Ring Kit	1 Set
12. 	Felt Plug	1 PC
13. 	Felt Ring	2 PC
14. 	Shim .03	4 pc
15. 	Shim .05	4 PC
16. 	Shim .10	4 PC
17. 	Sight Glass	1 PC
18. 	Shaft Key QDP80	6 PC
19. 	Motor Gasket	1 PC