

Alcatel A300 Repair Kit

1. 		Bearing	2. 		Bearing
		2 pcs			2 pcs
3. 		Teflon Seal	4. 		Teflon Seal
		2 pcs			2 pcs
5. 		Teflon Ring	6. 		Teflon Ring
		1 pc			1 pc
7. 		Teflon Ring	8. 		Teflon Ring
		2 pc			7 pc
9. 		Teflon Ring	10. 		Sleeve
		1 pc			2 pc
11. 		O-ring Set			
		1 pc			